## Cow pusher without a manure scraper





The cow pusher with is a metal structure separating a group of cows in front of the milking parlour (holding pen). The structure activates behind the last cow in the group and gently pushes the entire group towards the milking parlour. An electric motor ensures the cow pusher's movement along the channel. After the last cow in the group enters the milking parlour, the staff picks up the pusher by pressing the corresponding button on the control panel. The pusher structure passes over the holding pen in a raised position, over the heads of the next group of animals waiting to enter the milking parlour, and moves down behind them. The whole process is repeated.


The cow pusher is controlled by the operator or milking operator, directly from the milking parlour. The pusher's presence significantly speeds-up the process of pushing animals into the milking parlour, reduces the animals' stress associated with the staff activities, and saves on labour force. If the cow pusher encounters an obstacle (animal or rubber stop at the end of the channel), the electric motor switches off based on the limit switch signal. After removing the obstacle (the animal leaves) or by manually switching the direction of movement (the pusher reaches the stop), the pusher continues to move in the specified direction.

The cow pusher is equipped with an electric buzzer signalling its movement towards the milking parlour.



## INSTALLATION VARIANTS WITH REGARD TO THE FLOOR SURFACE

INSTALLATION INTO CONCRETE FLOOR



INSTALLATION ON CONCRETE FLOOR IS ALSO POSSIBLE



INSTALLATION ON A CONCRETE GRID

## **SIMPLE OPERATION**

The cow pusher comes with several control panels, which, for the convenience of the employees, are placed both in the holding pen and in the milking parlor. The main control panel P5 controls all the functions of the cow pusher. Generally, it is placed in the entrance of the holding pen and is out of reach of the dairy cows.

There are also auxiliary control panels, which are located in the milking parlor (D2 panel), as well as in the aisle between the holding pen and the milking parlor (C3 panel). The auxiliary control panels have more limited control functions than the main one, but every each of them can stop the cow pusher in any position.

## **BASICTECHNICAL DATA**

Standard range of pusher axial

width dimensions (channel axis): 3,000 – 11,800 mm

Maximum channel length: 25,000 mm

Height from the holding

pen floor: 2,750 mm

 $Maximum\, slope\, of\, the\, holding$ 

pen floor: 4°

Holding pen gate height: 1,970 mm Channel height: 1,650 mm

Total weight up to: 800 kg (type 11,800 mm)

Travel speed: 4 m/min.





FARMTEC a.s., Tisová 326, 391 33 Jistebnice Czech Republic

Mgr. Iryna Kukovich, e-mail: ikukovich@farmtec.cz mob.: +420 606 040 280 Ing. Jan Krampl, e-mail: jkrampl@farmtec.cz mob.: +420 702 226 841



